

Iveco Daily 89-96

**HU-IV3001G-FR**  
**HU-IV3001G-FL**

Iveco  
Iveco Daily 89-96  
Outside Handle  
Front RH;LH  
G:Light Gray  
FR:93927792  
FL:93927401



10pcs/2-3kg/1'

Iveco Daily 96-99

**HU-IV3002G-FR**  
**HU-IV3002G-FL**

Iveco  
Iveco Daily 96-99  
Outside Handle  
Front RH;LH  
G:Dark Gray  
FR:93936135  
FL:93936134



10pcs/2-3kg/1'

Iveco Daily 00-

**HU-IV3003A-FR**  
**HU-IV3003A-FL**

Iveco  
Iveco Daily 00-07  
Outside Handle  
Front RH;LH  
A:Plastic Black Texture  
FR:99489590  
FL:99489589



10pcs/2-3kg/1'

**HU-IV2003A-FR**  
**HU-IV2003A-FL**

Iveco  
Iveco Daily 00-07  
Inside Handle  
Front RH;LH  
A:Black Texture  
FR:500314228  
FL:500314227



100pcs/8-9kg/1.7'

**HU-IV3003A-Set**

Iveco  
Iveco Daily 00-07  
2 Outside Handle+  
2 Inside Handle  
4 pcs/ Sets



Eurocargo,Eurotech, Stralis 96-03

**HU-IV3005A-FR**  
**HU-IV3005A-FL**

Iveco  
Eurocargo,Eurotech,Stralis 96-03  
Front RH;LH  
A:Plastic Black Texture  
FR: 98404709  
98404713  
500335296R  
FL: 98404710  
98404714  
500335296L



10pcs/3-4kg/1'

**HU-IV2005A**

Iveco  
Eurocargo,Eurotech  
Stralis 96-03  
Inside Handle  
Front RH=LH  
98472613



100pcs/3-4kg/1.7'

**HU-IV8005-1C2K**

Iveco  
Eurocargo,Eurotech, Stralis  
Key Cylinder Lock  
1 Cylinder + 2 Keys



100pcs/4-5kg/1'

Eurocargo,Eurotech, Stralis 03-

**HU-IV3006A-FR**  
**HU-IV3006A-FL**

Iveco  
Eurocargo,Eurotech  
Stralis 03-  
Outside Handle  
Front RH;LH  
A:Plastic Black Texture  
FR:504052936R  
FL:504052936L



10pcs/3-4kg/1'

**HU-IV2006A**

Iveco  
Eurocargo,Eurotech  
Stralis 03-  
Inside Handle  
Front RH=LH  
A:Plastic Black Texture  
504060738  
98472610



100pcs/3-4kg/1.7'

**HU-IV8006-1C2K**

Iveco  
Eurocargo,Eurotech, Stralis  
Key Cylinder Lock  
1 Cylinder + 2 Keys  
2992664



100pcs/4-5kg/1'

## International Truck

**HU-IN001-RH**  
**HU-IN001-LH**

International  
Truck 84-05  
Door Lock  
RH;LH  
RH:498003C2-RH  
LH:498003C2-LH



50pcs/12-13kg/0.8'

**HU-IN006-RH**  
**HU-IN006-LH**


International  
Truck 84-05  
Handle Case  
RH;LH  
Steel  
RH:1649759C1



100pcs/0.8'

**HU-IN002-RH**  
**HU-IN002-LH**

International  
Truck 84-05  
Lock  
RH;LH  
RH:578065C2-RH  
LH:578065C2-LH



50pcs/12-13kg/0.8'

**HU-IN007**

International  
Truck 84-05  
Headlight Screw  
500565C91



100pcs/0.3'

**HU-IN003**

International  
Truck 84-05  
Outside Handle  
RH=LH  
M:Zinc Chrome  
1680789C91



50pcs/18-19kg/1.7'

**HU-IN008**

International  
Truck 84-05  
Stricker Bolt  
496448C2



100pcs/0.3'

**HU-IN004S-RH**  
**HU-IN004S-LH**

International  
Truck 84-05  
Inside Handle  
RH;LH  
S:Zinc Black  
LH:1649758C1



50pcs/14-15kg/1.1'

**HU-IN009-RH**  
**HU-IN009-LH**

International  
Truck 84-05 (Old)  
Window Regulator  
RH;LH  
Manual



10pcs/8-9kg/1.7'

**HU-IN004M-RH**  
**HU-IN004M-LH**

International  
Truck 84-05  
Inside Handle  
RH;LH  
M:Zinc Chrome



50pcs/14-15kg/1.1''

**HU-IN010-RH**  
**HU-IN010-LH**

International  
Truck 84-05 (NEW)  
Window Regulator  
RH;LH  
Manual  
LH:1686704C91



10pcs/8-9kg/1.7'

**HU-IN005S**

International  
Truck 84-05  
Window Regulator Handle  
S:Zinc Black  
1649776C



250pcs/18-19kg/1.7'